

“IMMEDIATE IMPLANTS – INDICATIONS, RISKS, AND BENEFITS”

RONALD P MORRIS, DDS
Oral & Maxillo-facial Surgeon
Downriver Surgery Center
1823 Fort, Wyandotte, MI 48192
734-285-2550 DRronoms@aol.com
Website: downriversurgery.com

Hand outs

- ▣ Open cell phone/laptop browser
- ▣ Type in “downriversurgery.com”
- ▣ Click on website
- ▣ Click on “Material for Professionals”
- ▣ Click on “Immediate Implants”
- ▣ Slide presentation should open and enjoy!

Review of procedures:


- ▣ Extraction of Mandibular 1st molar and Immediate wide diameter implant and graft
- ▣ Extraction of Maxillary 1st molar and Immediate wide diameter implant with sinus lift and graft
- ▣ Extraction of Maxillary Central Incisor with Immediate implant, immediate abutment, immediate temporary, and socket graft

A complete set of 25 interchangeable tips and a universal handle to facilitate the closed sinus lift procedure.

BONE SPREADING KIT

BONEKIT

Signature Series® Cassette for Bone Spreading Kit	IMDINOST
2.7mm Osteotome Tapered Convex Straight Tip	OSTMSP27
3.2mm Osteotome Tapered Convex Straight Tip	OSTMSP32
3.7mm Osteotome Tapered Convex Straight Tip	OSTMSP37
4.2mm Osteotome Tapered Convex Straight Tip	OSTMSP42
5.0mm Osteotome Tapered Convex Straight Tip	OSTMSP50
2.7mm Osteotome Tapered Convex Angulated Tip	OSTMSP27A
3.2mm Osteotome Tapered Convex Angulated Tip	OSTMSP32A
3.7mm Osteotome Tapered Convex Angulated Tip	OSTMSP37A
4.2mm Osteotome Tapered Convex Angulated Tip	OSTMSP42A
5.0mm Osteotome Tapered Convex Angulated Tip	OSTMSP50A
2.7mm Osteotome Tapered Concave Straight Tip	OSTMSH27
3.2mm Osteotome Tapered Concave Straight Tip	OSTMSH32
3.7mm Osteotome Tapered Concave Straight Tip	OSTMSH37
4.2mm Osteotome Tapered Concave Straight Tip	OSTMSH42
5.0mm Osteotome Tapered Concave Straight Tip	OSTMSH50
2.7mm Bone Condenser Slightly Convex Straight Tip	OSTMPU27
3.2mm Bone Condenser Slightly Convex Straight Tip	OSTMPU32
3.7mm Bone Condenser Slightly Convex Straight Tip	OSTMPU37
4.2mm Bone Condenser Slightly Convex Straight Tip	OSTMPU42
5.0mm Bone Condenser Slightly Convex Straight Tip	OSTMPU50
2.7mm Osteotome Angulated Tip	OSTMPU27A
3.2mm Osteotome Angulated Tip	OSTMPU32A
3.7mm Osteotome Angulated Tip	OSTMPU37A
4.2mm Osteotome Angulated Tip	OSTMPU42A
5.0mm Osteotome Angulated Tip	OSTMPU50A
Interchangeable Osteotome Handle	OSTMGRIF



TECHNICAL DATA:

Osteotomes (tapered diameter)	Bone Pushers (cylindrical diameter)
#1 (2.0-2.7mm)	#1 (2.7mm)
#2 (2.7-3.2mm)	#2 (3.2mm)
#3 (3.2-3.7mm)	#3 (3.7mm)
#4 (3.7-4.2mm)	#4 (4.2mm)
#5 (4.2-5.0mm)	#5 (5.0mm)




Signature Series
Cassette
for Bone
Spreading Kit
IMDINOST



Interchangeable
Osteotome handle

OSTMGRIF
Fits all Hu-Friedy
bone spreading
tips.



Impact Air 45



Palisades Dental LLC



HOME

ABOUT US

PRODUCTS

SALES

SUPPORT

CONTACT



Geistlich Bio-Oss





Smarter thinking. Simpler design.™



Indication Specific Implant Options

TiLobeMAXX & Genesis



Extraction of Mandibular 1st Molar with Immediate Implant

- ▣ Case selection: Ideal with no infection and intact buccal and lingual cortical plates
- ▣ No soft tissue defects
- ▣ Pre-operative x-rays; prefer 3D cone beam if possible but not mandatory
- ▣ Assess lingual undercut
- ▣ Medical risk factors: diabetes, smoker, heavy Etoh use, poor oral hygiene, and immune system disorders



Extraction of Mandibular 1st Molar with Immediate Implant

- ▣ Preoperative antibiotics-ideal 5 days of Keflex 500mg QID or Cleocin 150mg QID
- ▣ Preoperative Motrin 800mg or plain Tylenol 500mg
- ▣ Peridex or comparable preoperative mouth rinse
- ▣ Sedation orally or IV if warranted
- ▣ Opposing arch impression in alginate
- ▣ Preoperative photographs and shade selection

Extraction of Mandibular 1st Molar with Immediate Implant

- ▣ Atraumatic extraction and flapless (release of papilla only if necessary, for elevator)
- ▣ Plan on high speed sectioning with lots of irrigation
- ▣ Remove interseptal bone almost flush with cortical plates, again with lots of irrigation and light touch
- ▣ Thoroughly curette any granulation tissue and PDL

Extraction of Mandibular 1st Molar with Immediate Implant


- ❑ Consider rinsing with hydrogen peroxide for decontamination, and rinse thoroughly with sterile water or saline.
- ❑ Measure socket depth on mesial and distal against both buccal and lingual cortical plates
- ❑ Most of the time you will not need to engage full depth of socket
- ❑ Determine ideal implant length with 2mm counter sink from lowest marginal ridge, most likely will be 9 mm or 11mm long

Keystone Dental History

- ▣ LifeCore Biomedical was one of the first implant companies. 30 years of research
- ▣ Keystone Dental acquired LifeCore in 2007 and became it's own company.
- ▣ Developed a full line of biomaterials including our flagship DynaBlast bone putty and DynaMatrix bioactive membrane
- ▣ Merged with Southern Implants in 2012- which brought us the Max wide-diameter implant

MAX Implants

Keystone Dental Acquired Southern Implants in 2012



Internal Tri-Lobe



Internal Hexagon



Internal TriLobe




Internal Octagon/
Morse Taper



External Hexagon

INDICATION
SPECIFIC
IMPLANT
OPTIONS

TiLobeMAXX






Immediate Placement Advantages

- Shorter treatment time - allows for immediate placement following extraction
- Fewer surgical procedures - minimizes the need for grafting, regenerating, implant placement protocol
- Wider implant design maximizes bone preservation
- Soft tissue preservation – improves emergence profile
- Reduced patient discomfort -
- Superior esthetic result – no food traps
- Patient satisfaction – reduces time and costs

TiLobeMAXX® Connection


- MAX-TL \varnothing 7.0 mm Implants feature a \varnothing 5.5 mm platform. Prima (5.0) or Genesis (5.5/6.5) abutments are available in a flare 6.0 mm.
- MAX-TL \varnothing 8.0 mm Implants feature a \varnothing 6.5 mm platform. Prima (5.0) or Genesis (5.5/6.5) abutments are available in a flare of 6.0 mm.
- MAX-TL \varnothing 9.0 mm Implants feature a \varnothing 7.5 mm platform. Separate abutments are available in a flare of 7.0 mm. **Can also be used on the \varnothing 8.0 mm implants**



TiLobeMAXX Dental Implant System


Design Features

The MAX Implants features a body with a larger-than-conventional diameter to fill a molar site, ultimately achieving primary stability by engaging the perimeter of the bony wall. The MAX-TL Implant has a tapered body, an enhanced surface and is designed to fit the natural shape of the molar socket. The MAX-TL Implant provides an optimal fit in the multi-rooted immediate extraction site, minimizing bone loss and reducing treatment time.



TiLobeMAXX Dental Implant System

- 7 mm, 8 and 9 mm diameter implant
-
- Greater tapered body
 - Engages the apical intra-radicular bone
 - Fits tapered socket
 - Avoids lateral sinus perforation
 - Avoid adjacent roots
 - Conservation of bony walls
 - Superior primary stability



Enhanced Surface Technologies

- Proprietary surface similar to SLA
- Consistent, well-controlled process
- Performance well-documented over 13 years in peer-reviewed literature
- *Clinical Oral Implants Research Journal*, Volume 13:86-93
- *Clinical Implant Dentistry and Related Research*, 2003; Volume 5:3m


Keystone Max implant

- ❑ Check fit with implant profile gauges, start with 7 mm wide by 9 mm long, verify that it goes in at the projected angle, rarely will bind with Mandibular first molars sites.
- ❑ Check gap on buccal and lingual, if loose, go to 8mm wide by 7 mm long and recheck buccal and lingual gap, this size most of the time will be tight and go about 1 mm above crest or flush with the crest.
- ❑ Run slowly the intermediate drill down to desired depth, most likely 11mm from lowest (most apical) portion of the crest.
- ❑ Slow speeds 150-450 rpm and hold the drill firmly, it will want to “chatter”

Site preparation

- ▣ Use final drill down one size (i.e.-7mm wide for 8mm wide implant) for the implant selected, take to full depth
- ▣ Use tap drill, again one diameter size down from final implant diameter, (tap speed 50-75 rpm), being careful to make sure you have proper alignment
- ▣ Run tap down to desired depth
- ▣ Mount implant on fixture mount and at tap speed drive it down till torque limiter releases, most likely will be flush with crest
- ▣ Recheck alignment is still good, and place manual driver sleeve and wrench on fixture mount, and torque to final position usually 60+ Ncm
- ▣ May need to back off $\frac{1}{4}$ turn for every $\frac{1}{2}$ turn down till final seat

MAX Dental Implant System



MAX Dental Implant System

Ø8.0 x 9.0 mm





MAX Dental Implant System



Courtesy of Dr. Rick Smith
The NY Center For Specialized Dentistry NYC,
NY

MAX Dental Implant System


Implant Sizing - Mandibular First Molar



Tri-MAX Dental Implant System


Clinical Suggestions

- In the Mandibular posterior it is recommended for placement to be **sub-crestal 2.0 mm, towards the lingual, and 2.0 mm away from the buccal wall** for bone to cover the threads



MAX Dental Implant System

Clinical Solutions



Mandible MAX
2 years post-op



Courtesy of Dr. A. Hattingh,
Perio

MAX Dental Implant System



Courtesy of Dr. Rick Smith
The NY Center For Specialized Dentistry NYC,
NY

Prosthetics for the TiLobeMAXX


Impression Posts

- Closed/open Tray, except 9.0mm
- Matches the flare of the healing abutment
- Flare – 7.0 mm



Final Abutment for TiLobeMaxx Implant

- Anatomical contours
- Natural emergence profile diameters for a natural esthetic emergence through the soft tissue
- Supports the inter-dental papilla
- Available in 7.0 mm flare



TiLobeMAXX®

Keystone Dental's MAX-TL® implants incorporate TiLobe® Technology, a patented internal 6-lobed connection that provides a stable foundation for life-long esthetic results by honoring the principles of biology and bio-mechanics.

Synergy Through Strength And Stability

- **Self-sealing coronal taper**
- **6 lobe internal design**
- **Tight tolerances**



Southern Implant Tri-Max

▣ Standard site preparation sequence

Tri-MAX Surgical Sequence (Tri-MAX Ø9 x 11 mm)


The Tri-MAX implant features a body with a wider than conventional diameter to fill a molar site. The buccal plate and sinus (maxilla) must be intact when placing a Tri-MAX. The implant must be placed 2 mm from the buccal plate and 2 mm below the lowest part of the crest to avoid thread exposure due to possible bone resorption. For more information please consult the Southern Implants Inc. Surgical Manual.



Surgical Pointers for bone type I/II:

- Progressively widen the osteotomy with intermediate drills (*)
- Properly align the latch-type instrument within the drill extension and /or hand piece
- Only use drill extension when absolutely necessary
- Rotate the latch-type instrument when engaging into W&H hand piece to ensure proper seating

The Bone Tap can be converted into a wrench insert by using the Converter to Wrench (i-WI-C-S) to avoid instrument deformation with the hand piece.



Products shown are not to scale.

SIM-12-241MX


Graft and impression

- ❑ Remove fixture mount and insert impression pin with some Neosporin cream on threads
- ❑ May want to place some graft at this time depending on whether there are “gaps” on the mesial and distal. Impression material can easily flow down these gaps and become very hard to remove, if not impossible
- ❑ Graft needs to be small particle size and slow resorbing such as Bio-Oss or Ingenious HA
- ❑ Pack graft tightly and make sure it is soaked with blood
- ❑ Fill only to top of implant at this time
- ❑ Take impression-VPS medium to light body, fast set

Healing abutment & addition grafting

- ❑ After impression verify that indexing flat is visible, and no major bubbles on contact areas of adjacent teeth
- ❑ Remove impression pin and insert healing abutment, add small amount of additional Neosporin cream and rinse
- ❑ Graft remaining socket till filled just short of gingival margin, all tissue must be supported
- ❑ Place gel foam “membrane” over grafted areas if bigger than 2mm wide
- ❑ Suture only if tissue is loose or papilla was released
- ❑ Seal with tissue glue
- ❑ Bite registration if needed

Immediate Mandible Molar implant



Immediate Mandible Molar implant



(Video)

Immediate Mandible Molar implant



(Video)

Post Op



Immediate Maxillary 1st Molar Implant

With Trans-Alveolar sinus lift/graft



- ▣ Similar to immediate Mandibular molar ultra wide implant placement for indications and work up 3D Cone beam almost a must
- ▣ Careful, atraumatic tooth extraction-must section for removal and avoid buccal cortical plate
- ▣ Curette out all granulation tissue, and scrape PDL
- ▣ Consider rinsing with hydrogen peroxide for decontamination, and rinse thoroughly with sterile water or saline.

Immediate Maxillary 1st Molar Implant

- ▣ Measure socket depth on MB, DB, and palatal roots against both buccal and lingual cortical plates
- ▣ Most of the time you will not need to engage full depth of socket
- ▣ Determine ideal implant length with 2mm counter sink from lowest marginal ridge, most likely will be 9 mm or 11mm long

MAX Dental Implant System


Implant Sizing - Maxillary First Molar



Tri-MAX Dental Implant System

Clinical Suggestions

- In the maxillary posterior it is recommended for placement to be **sub-crestal 2.0 mm, towards the mesial of the extraction socket, and 2.0 mm away from the buccal wall** for bone to cover threads.



Tri-MAX Dental Implant System

Clinical Solutions



Maxilla



Courtesy of Dr. A. Ackermann

Clinical Case




Courtesy of Dr. A. Hattingh, Perio

Clinical Case




Courtesy of Dr. A. Hattingh, Perio

Clinical Case




Courtesy of Dr. A. Hattingh, Perio

Clinical Case



Courtesy of Dr. A. Hattingh, Perio

Immediate Maxillary 1st Molar Implant




(Video)

Immediate Maxillary 1st Molar Implant



(Video)

Post Op



Tooth #8 (tooth in a day)

- ▣ Surgical removal of tooth #8 with horizontal root fracture
- ▣ Immediate implant placement with combination of drills and osteotomes
- ▣ Placement of socket graft
- ▣ Fabrication of immediate custom temporary abutment
- ▣ Fabrication and cementation of immediate temporary tooth

Implants by System

InterActive™ System

Legacy™ System

Tri-lobe System

Swish™ System


Spectra-System®

Legacy™ 1

Legacy™ 2

Legacy™ 3

Legacy™ 4



Internal Hex Implants

Tooth #8 (tooth in a day) Indications/Advantages

- ▣ Patient has only one surgery, compared to three
- ▣ Faster treatment time to final crown, 3 months versus 12 months
- ▣ Better support of and maintenance of hard and soft tissues of the esthetic zone

Tooth #8 (tooth in a day)

Indications

- ❑ Case selection: Ideal with no or minimal infection and intact buccal and lingual cortical plates at the crest
- ❑ No major hard or soft tissue defects
- ❑ Pre-operative x-rays; prefer 3D cone beam if possible but not mandatory
- ❑ Medical risk factors/Contraindications: diabetes, smoker, heavy Etoh use, poor oral hygiene, and immune system disorders

Tooth #8 (tooth in a day) Sequence of Treatment

- ▣ Preoperative antibiotics-ideal 5 days of Keflex 500mg QID or Cleocin 150mg QID
- ▣ Preoperative Motrin 800mg or plain Tylenol 500mg
- ▣ Peridex or comparable preoperative mouth rinse
- ▣ Sedation orally or IV if warranted
- ▣ Opposing arch impression in alginate
- ▣ Preoperative photographs and shade selection
- ▣ Preoperative implant selection if 3DCB available, otherwise for centrals and canines a 4.5-5.0mm diameter by 13-16mm length implant. 3.5-4.0 diameter for lateral incisors

Tooth #8 (tooth in a day)

Sequence of treatment

- ❑ Local anesthesia-usually start with 3% Carbocaine plain, followed by 2% Lidocaine with Epi, and then 0.5% Marcaine with Epi (should be able to start immediately)
- ❑ Sulcular incision only with micro blade or #11 blade (try not to release papilla)
- ❑ Attempt removal with forceps. Recommend serrated or diamond coated. Keep slow steady rotational pressure-TAKE YOUR TIME
- ❑ If removing an existing crown to be used as a temporary, protect crown with gauze or a small piece of rubber dam, and very light “squeezing” force on the forceps. If successful hollow out crown with a coarse round diamond (#4) or football shape and lots of irrigation

Tooth #8 (tooth in a day)

Sequence of treatment

- ❑ Removal of remaining root: Use Woodson, microtomes, or piezoelectric ultrasonic (chisel tips)
- ❑ Thoroughly debride PDL and any peri-apical pathology
- ❑ Consider socket decontamination/irrigation with Plain hydrogen peroxide, sterile saline, and possibly Peridex
- ❑ Directly measure socket with periodontal probe to buccal and palatal crest of bone and soft tissue, have someone record this!
- ❑ Plan on counter sinking 2 mm below the lowest point of the bony crest, usually the buccal
- ❑ Check integrity of the cortical plates, especially the buccal


Tooth #8 (tooth in a day)

Sequence of treatment

- ❑ Check angulation of socket compared to adjacent roots, usually socket tapers toward the buccal
- ❑ Start preparation with the Lindeman drill with extender attached and angle most of the time towards the palate, once engaged straighten the drill to the ideal angle and drill in a few millimeters (3-5mm) and remeasure
- ❑ Continue with Lindeman drill to just sort of final depth, for a 16 mm implant + 2mm countersink + soft tissue thickness(1.5-2mm)
- ❑ Insert small diameter osteotome and “push” or mallet to final depth, then continue drilling with pilot drill 2.3 mm



Complete Surgical Tray



Surgical Tray Contents		Price
Description		
ST	Surgical Tray (Empty)	\$250.00
SD2.3	2.3/2.0mmD Step Drill-Long	\$60.00
SD2.3S	2.3/2.0mmD Step Drill-Short	\$60.00
SD2.8	2.8/2.3mmD Step Drill-Long	\$60.00
SD2.8S	2.8/2.3mmD Step Drill-Short	\$60.00
CBD3.2	3.2mmD Cortical Drill	\$60.00
SD3.4	3.4/2.8mmD Step Drill-Long	\$60.00
SD3.4S	3.4/2.8mmD Step Drill-Short	\$60.00
CBD3.7	3.7mmD Cortical Drill	\$60.00
SD3.8	3.8/3.4mmD Step Drill-Long	\$60.00
SD3.8S	3.8/3.4mmD Step Drill-Short	\$60.00
CBD4.2	4.2mmD Cortical Drill	\$60.00
SD4.4	4.4/3.8mmD Step Drill-Long	\$60.00
SD4.4S	4.4/3.8mmD Step Drill-Short	\$60.00
CBD4.7	4.7mmD Cortical Drill	\$60.00
SD4.8	4.8/4.4mmD Step Drill-Long	\$60.00
SD4.8S	4.8/4.4mmD Step Drill-Short	\$60.00
CBD5.2	5.2mmD Cortical Drill	\$60.00
D5.1	5.1mmD Straight Drill-Long	\$60.00
D5.1S	5.1mmD Straight Drill-Short	\$60.00
SD5.4	5.4/4.8mmD Step Drill-Long	\$60.00
SD5.4S	5.4/4.8mmD Step Drill-Short	\$60.00
CBD5.7	5.7mmD Cortical Drill	\$60.00
Hex Tools		
THT1.25	1.25mmD Tapered Hex Tool-Long	\$40.00
THT1.25S	1.25mmD Tapered Hex Tool-Short	\$40.00
HT1.25	1.25mmD Straight Hex Tool-Long	\$40.00
HT1.25S	1.25mmD Straight Hex Tool-Short	\$40.00
HT2.0	2.0mmD Hex Tool-Long	\$40.00
HT2.0S	2.0mmD Hex Tool-Short	\$40.00
HT2.5	2.5mmD Hex Tool-Long	\$40.00
HT2.5S	2.5mmD Hex Tool-Short	\$40.00
HT3.0	3.0mmD Hex Tool-Long	\$40.00
HT3.0S	3.0mmD Hex Tool-Short	\$40.00
HD1.25	1.25mmD Hex Drill	\$40.00
HD2.0	2.0mmD Hex Drill	\$40.00
HD2.5	2.5mmD Hex Drill	\$40.00
HD3.0	3.0mmD Hex Drill	\$40.00
Ancillary Instrumentation		
FMD	Fixture Mount Drill	\$80.00
LDRILL	Locator Drill	\$30.00
DE	Drill Extender	\$40.00
R	Ratchet	\$125.00
PAR (x4)	Paralleling Tool 2.8/2.3	\$60.00
SSH2.5	2.5mmD Stainless Steel Handle	\$100.00
		\$2,565.00


Lindemann bur





SD2.3 SD2.3S

Complete Surgical Tray




Surgical Tray Contents		Price
Description		
ST	Surgical Tray (Empty)	\$250.00
SD2.3	2.3/2.0mmD Step Drill-Long	\$60.00
SD2.3S	2.3/2.0mmD Step Drill-Short	\$60.00
SD2.8	2.8/2.3mmD Step Drill-Long	\$60.00
SD2.8S	2.8/2.3mmD Step Drill-Short	\$60.00
CBD3.2	3.2mmD Cortical Drill	\$60.00
SD3.4	3.4/2.8mmD Step Drill-Long	\$60.00
SD3.4S	3.4/2.8mmD Step Drill-Short	\$60.00
CBD3.7	3.7mmD Cortical Drill	\$60.00
SD3.8	3.8/3.4mmD Step Drill-Long	\$60.00
SD3.8S	3.8/3.4mmD Step Drill-Short	\$60.00
CBD4.2	4.2mmD Cortical Drill	\$60.00
SD4.4	4.4/3.8mmD Step Drill-Long	\$60.00
SD4.4S	4.4/3.8mmD Step Drill-Short	\$60.00
CBD4.7	4.7mmD Cortical Drill	\$60.00
SD4.8	4.8/4.4mmD Step Drill-Long	\$60.00
SD4.8S	4.8/4.4mmD Step Drill-Short	\$60.00
CBD5.2	5.2mmD Cortical Drill	\$60.00
D5.1	5.1mmD Straight Drill-Long	\$60.00
D5.1S	5.1mmD Straight Drill-Short	\$60.00
SD5.4	5.4/4.8mmD Step Drill-Long	\$60.00
SD5.4S	5.4/4.8mmD Step Drill-Short	\$60.00
CBD5.7	5.7mmD Cortical Drill	\$60.00
Hex Tools		
THT1.25	1.25mmD Tapered Hex Tool-Long	\$40.00
THT1.25S	1.25mmD Tapered Hex Tool-Short	\$40.00
HT1.25	1.25mmD Straight Hex Tool-Long	\$40.00
HT1.25S	1.25mmD Straight Hex Tool-Short	\$40.00
HT2.0	2.0mmD Hex Tool-Long	\$40.00
HT2.0S	2.0mmD Hex Tool-Short	\$40.00
HT2.5	2.5mmD Hex Tool-Long	\$40.00
HT2.5S	2.5mmD Hex Tool-Short	\$40.00
HT3.0	3.0mmD Hex Tool-Long	\$40.00
HT3.0S	3.0mmD Hex Tool-Short	\$40.00
HD1.25	1.25mmD Hex Drill	\$40.00
HD2.0	2.0mmD Hex Drill	\$40.00
HD2.5	2.5mmD Hex Drill	\$40.00
HD3.0	3.0mmD Hex Drill	\$40.00
Ancillary Instrumentation		
FMD	Fixture Mount Drill	\$80.00
LDRILL	Locator Drill	\$30.00
DE	Drill Extender	\$40.00
R	Ratchet	\$125.00
PAR (x4)	Paralleling Tool 2.8/2.3	\$60.00
SSH2.5	2.5mmD Stainless Steel Handle	\$100.00
		\$2,565.00

Tooth #8 (tooth in a day)

Sequence of treatment

- ▣ Start using irrigation at this point and drill next sequence up alternating a larger osteotome inserted to compress the bone laterally.
- ▣ Drill slow usually around 300-450 RPM
- ▣ Carefully check alignment each time you insert a drill or osteotome
- ▣ Implant angle in most cases is not going to fall on incisal edge
- ▣ Drill/compress “one sequence” short of final drill size I.E.- 3.8 mm diameter for a 4.7 drill or 2.8 mm for a 3.7 mm implant



cal Tray

Surgical Tray Contents

Description		Price
ST	Surgical Tray (Empty)	\$250.00
SD2.3	2.3/2.0mmD Step Drill-Long	\$60.00
SD2.3S	2.3/2.0mmD Step Drill-Short	\$60.00
SD2.8	2.8/2.3mmD Step Drill-Long	\$60.00
SD2.8S	2.8/2.3mmD Step Drill-Short	\$60.00
CBD3.2	3.2mmD Cortical Drill	\$60.00
SD3.4	3.4/2.8mmD Step Drill-Long	\$60.00
SD3.4S	3.4/2.8mmD Step Drill-Short	\$60.00
CBD3.7	3.7mmD Cortical Drill	\$60.00
SD3.8	3.8/3.4mmD Step Drill-Long	\$60.00
SD3.8S	3.8/3.4mmD Step Drill-Short	\$60.00
CBD4.2	4.2mmD Cortical Drill	\$60.00
SD4.4	4.4/3.8mmD Step Drill-Long	\$60.00
SD4.4S	4.4/3.8mmD Step Drill-Short	\$60.00
CBD4.7	4.7mmD Cortical Drill	\$60.00
SD4.8	4.8/4.4mmD Step Drill-Long	\$60.00
SD4.8S	4.8/4.4mmD Step Drill-Short	\$60.00
CBD5.2	5.2mmD Cortical Drill	\$60.00
D5.1	5.1mmD Straight Drill-Long	\$60.00
D5.1S	5.1mmD Straight Drill-Short	\$60.00
SD5.4	5.4/4.8mmD Step Drill-Long	\$60.00
SD5.4S	5.4/4.8mmD Step Drill-Short	\$60.00
CBD5.7	5.7mmD Cortical Drill	\$60.00
Hex Tools		
THT1.25	1.25mmD Tapered Hex Tool-Long	\$40.00
THT1.25S	1.25mmD Tapered Hex Tool-Short	\$40.00
HT1.25	1.25mmD Straight Hex Tool-Long	\$40.00
HT1.25S	1.25mmD Straight Hex Tool-Short	\$40.00
HT2.0	2.0mmD Hex Tool-Long	\$40.00
HT2.0S	2.0mmD Hex Tool-Short	\$40.00
HT2.5	2.5mmD Hex Tool-Long	\$40.00
HT2.5S	2.5mmD Hex Tool-Short	\$40.00
HT3.0	3.0mmD Hex Tool-Long	\$40.00
HT3.0S	3.0mmD Hex Tool-Short	\$40.00
HD1.25	1.25mmD Hex Drill	\$40.00
HD2.0	2.0mmD Hex Drill	\$40.00
HD2.5	2.5mmD Hex Drill	\$40.00
HD3.0	3.0mmD Hex Drill	\$40.00
Ancillary Instrumentation		
FMD	Fixture Mount Drill	\$80.00
LDRILL	Locator Drill	\$30.00
DE	Drill Extender	\$40.00
R	Ratchet	\$125.00
PAR (x4)	Paralleling Tool 2.8/2.3	\$60.00
SSH2.5	2.5mmD Stainless Steel Handle	\$100.00

\$2,565.00

Tooth #8 (tooth in a day)

Sequence of treatment

- ❑ Remove implant and either mount on fixture mount or manual hand driver and insert implant into site holding tightly against palatal wall and ensure implant is engaging the prepared angle; it will want to push away towards the buccal
- ❑ If implant starts to “float” towards the buccal, back the implant off and reinsert, same procedure if it also binds with high torque on seating, remember “metal shop” one turn in, $\frac{1}{4}$ turn back!
- ❑ Notice hex flat position on implant and remove impression pin, drive implant down to final position with hex tool/ratchet, and try to finish hex parallel to buccal plate

Tooth #8 (tooth in a day) Sequence of treatment

- ❑ Prepare temporary plastic (PEEK) abutment by coating with Tenure(optional), blow dry and apply a thin coating of multilink automix down to margin and light cure; select a shade to use
- ❑ Try abutment onto implant keeping groove to buccal for orientation and estimate amount of additional multilink needed to fully support soft tissue at least 1-2 mm above the crest
- ❑ It is critically important that the abutment fully seats passively!!!!



Select a shade if available
Yellow is about B2 shade



Shades

Transparent, yellow, white (NEW) and opaque



Tooth #8 (tooth in a day)

Sequence of treatment

- ▣ Place cover cap on lightly with some Neosporin cream
- ▣ Reconstitute granular graft material with sterile water or left over local anesthesia (Marcaine) and pack down around implant, may need to use flat narrow instrument such as the Woodson to effecting get the material down the neck of the implant, pack firmly
- ▣ Replace cover cap with a straight impression pin; check to make sure the indexing flat is visible and fully seated; check for graft
- ▣ Fill impression pin access hole with soft rope wax and take impression in material of choice, VPS. Check impression for indexing flat and adjacent contacts

Tooth #8 (tooth in a day)

Sequence of treatment

- ▣ Remove impression pin carefully, clean any graft off the top of the implant, (Q-tip) and insert custom temporary abutment with additional small amount of Neosporin cream, and torque till solid, around 15-20 Ncm²
- ▣ Ideal prep abutment with coarse tapered diamond burr and copious irrigation flush with gingival crest
- ▣ Size plastic polycarbonate temporary crown to fit over prepped abutment or old crown if salvageable. Extend margins to gingival crest.
- ▣ Check occlusion with crown in position

70-2004-0991-7

001-3

3M ESPE Polycarbonate Crowns

- ⓓ Polycarbonatkronen
- ⓕ Couronne polycarbonate
- Ⓛ Corone provvisorie in policarbonato
- ⓔ Couronne polycarbonate
- Ⓟ Corona de Policarbonato
- ⓃL Polycarbonaat kroon
- ⓖR Πολυκαρβονούχες στεφάνες
- Ⓢ Polykarbonat kronor
- ⓕRNL Polykarbonaattikruunut
- ⓓK Polykarbonat Kroner
- Ⓝ Polykarbonat-krone

CONTENTS

180



C-180




3M ESPE
Polycarbonate Crowns - Adult Anterior

Tooth #8 (tooth in a day)

Sequence of treatment

- ❑ Fill access hole in temporary plastic abutment with soft rope wax
- ❑ Paint inside of temporary crown with Jet acrylic monomer and blow dry
- ❑ Thoroughly rinse abutment and dry
- ❑ Cement crown with Multilink automix dual cure resin cement
- ❑ Position carefully, clean excess cement, and light cure into position with patient in centric relation occlusion
- ❑ After fully cured, trim any excess cement with a high speed ultra fine flame diamond
- ❑ Check occlusion and adjust to being just out of contact
- ❑ Inject Decadron 4mg into vestibule for swelling/pain

Tooth #8 (tooth in a day) Sequence of treatment



(Video)

Tooth #8 (tooth in a day) Sequence of treatment



Post Operative Care

- ▣ Pain medications-usually Motrin 800 mg pre-op, if not immediately post-op Rx T#3 or Norco 7.5/325
- ▣ Keflex 500 mg QID (Cleocin 150 QID) for 10 days
- ▣ Over the counter sinus medications if the sinus floor has been elevated
- ▣ Ice/gel packs along with intra oral cold-slurpees, ice cream, ice chips
- ▣ Lightly brush area and rinse with salt water for first week, no flossing till sutures fall out

Post Operative Care

- ▣ Irrigation syringe starting on the 3rd day with salt water, after one week, move up to a mixture of 6 oz. of warm water, 1 oz. of hydrogen peroxide, and 1 oz. of mouthwash
- ▣ After 6 weeks move up to a water pik using the water, peroxide and mouthwash mixture at least at bedtime